

**Multimedia Instructions**  
**Armstrong Hall**

The multimedia system in this classroom is controlled using the video projector remote control. Make sure that you aim the remote control at the projector when using it.

To turn the projector on, press the POWER button on the remote control. It takes about 60 seconds for the projector to warm up.

To display the computer or laptop, press the "Comp" button on the remote. There is a gray switch box mounted at the desk that will allow you to switch between using the lab's computer and using a laptop. Press button one for the local computer, press button 2 for the laptop input.

To connect your laptop, connect VGA and audio to the output of your laptop. You may need to enable your laptop's VGA output. (This is done on Dell laptops by pressing Fn+F8, other laptops vary by manufacturer)

To use a the DVD / VHS Combination player, press the Video button on the projector's remote.

To make the volume louder or quieter, use the Volume buttons.

To turn off the system, press the Power Button on the remote control twice.

**MEDIA AND TECHNOLOGY SUPPORT SERVICES**  
**<http://www.tcnj.edu/~mtss>**